

Residential Backflow Prevention

[See Dual Check Valve Drawing](#)

The need to furnish reliable and inexpensive back-siphonage and backpressure protection for individual residences resulted in the debut of the residential dual check. Protection of the main potable supply from household hazards such as home photograph chemicals, toxic insect and garden sprays, termite control pesticides used by exterminators, etc. reinforce a true need for such a device.

It can be sized for ½", ¾", or 1" service lines and is installed immediately downstream of the water meter. The use of plastic check modules and elimination of test cocks and gate valves keeps the cost reasonable while providing good, dependable protection.

Example: Coppersetter - Installation

